


TEMPLATE / PLANTILLA / GABARITO FOR DEVICES / PARA LINEAS / LINHAS TOUCH, E-TOUCH & PAD

D1 (FIRE RESISTANT DEVICE/RESISTENTE AL FUEGO/RESISTENTES A FOGO)

D2 (NOT RESISTANT TO FIRE DEVICE/NO RESISTENTE AL FUEGO/NO RESIST. A FOGO)



DO NOT USE IN GLASS DOOR/NO USAR EN PUERTA DE VIDRIO/NAO UTILIZAR EM PORTA DE VIDRIO